ShoreTel 560/560g IP Phone Quick Reference

PHONE OPERATION

Place Calls

Use the Speakerphone or a Headset

Use the Directory

Make a Conference Call

Use the Intercom

Redial and Check Missed Calls

Dial Paging Extension

Answer Calls

Send a Call to Voice Mail

Divert a Call

Select a Ring Tone

Adjust Handset, Headset or Speakerphone Volume

Answer Call Waiting

Interact with Calls

Mute a Call

Place a Call On or Off Hold

Transfer a Call


Merge Calls

Park Calls

Unpark Calls

Change Availability State

Log In and Out of Workgroups **Adjust the Display Contrast**



VOICE MAIL

Log Into Main Menu

==== + password + ==== # | # | + ext. + password + [#]

Log In from Another Extension

Note: For more information about voice mail features, please consult the Voice Mail Quick Reference.

OFFICE ANYWHERE CODES

Transfer a call

Conference a call

Hold a call

Hang up

Access other star codes

* * + destination + * *

+ (star code from below)

QUICK REFERENCE OF COMMON STAR CODES

Park a call

UnPark a call

Pick Up a Remote Extension

Pick Up the Night Bell

Use the Intercom

Barge In

Silent Monitor

Toggle the Hunt Group Status

Whisper Page

Change Avail. State and Forwarding

Change Extension Assignment

Unassign Extension Assignment

Assign Extension to External Number

8 + HG ext.

+ password + #

+ password + #

+ password + (#)

+ password + # + 7

TROUBLESHOOTING

View Phone Information


Reboot Your Phone

Mute #

Note: For additional details on the information contained in this Quick Reference card, please consult the 560/560g User Guide.



ShoreTel 560/560g IP Phone Quick Reference



Note: You can connect a supported headset into the 560/560g IP Phone by plugging the headset into the headset jack at the left corner of the phone chassis. Contact your system administrator for details.


GUIDE TO LEDS

Your ShoreTel 560/560g IP phone provides color cues to help you determine the operational status. Note that these patterns apply to ShoreTel 6.1 (build 11.15.2603.0) and higher.

- Steady Green in use by you
- ▶ Blinking Green (Slow blink: 1s on/1s off) incoming call
- Blinking Orange (Fast blink: .25s on/.25s off) on hold or call parked
- O Steady Orange extension's availability state set to Do Not Disturb
- Steady Red in use by other party (applies to BCA and Extension Monitor)

GUIDE TO STATUS ICONS

ShoreTel IP 560/560g Idle Interface



ShoreTel IP 560/560g Inbound Call



Main Display

- Unheard Voice Messages
- Missed Calls
- ☐ Use Logged Into Workgroup, In Wrap-Up
- 🗗 🗐 Logged Out of Workgroup

Custom Keys - Call

- On Hook
- Off Hook
- Inactive / Do Not Disturb
- Incoming Call (Animated)
- On a Call
- On a Conference Call
- Lall On Hold / Parked
- Remote Hold

Custom Keys - Monitored Extension

- Idle
- Inactive / Do Not Disturb
- **Unheard Voice Messages**
 - Do Not Disturb / Unheard Messages
- Incoming Call (Animated)
- √ On a Call
- Incoming Call and On a Call
- On a Conference Call
- Call On Hold / Parked

Custom Keys - Speed Dial

Speed Dial Extension

ShoreTel, Inc., 960 Stewart Drive Sunnyvale, California 94085 USA Phone: +1.408.331.3300 +1.800.425.9385 Fax: +1.408.331.3333 www.shoretel.com

