
Mitel 6915 SIP Phone - Quick Reference Guide

Getting started



Basic call handling

Making a call

- 1. Lift the handset or press the \[\infty \lambda \(\) key, and at the dial tone, enter the number.
- 2. Press the Line / Call appearance button and at the dial tone, enter the number.



Ending or ignoring a call

Place the handset back in its cradle, press the **Ignore** softkey, or press the

key.

Answering a call

Lift the handset, press the Answer softkey or press the \(\) key for handsfree operation.

Redialing

Press the **Redial** softkey once or the key twice to call the last dialed number

Press the key once to access the Call History application that displays a list of recently dialed numbers. Use the up and down navigation keys to scroll through the entries and select a number. Press either the Select button or Dial softkey to redial the selected number.

Muting or unmuting a call

key while on an active call to mute the microphone for your handset, headset, or speaker. Press the key again to unmute the audio.

Holding and resuming a call

- key. A 🕕 (hold) icon flashes on the 1. To place an active call on hold, press the respective Line key.
- 2. To resume the call, press the key again or press the respective **Line** key.



and headset.

between the home screen,

the line manager, and active calls. void your warranty.

© Copyright 2024, Mitel Networks Corporation. All Rights Reserved.

may cause damage to the phone and will

58017009 REV00

The trademarks, service marks, logos and graphics (collectively "Trademarks") appearing on Mitel's Internet sites or in its publications are registered and unregistered trademarks of Mitel Networks Corporation (MNC) or its subsidiaries (collectively "Mitel") or others. Use of the Trademarks is prohibited without the express consent from Mitel. Please contact our legal department at legal@mitel.com for additional information. For a list of the worldwide Mitel Networks Corporation registered trademarks, please refer to the website:

Mitel 6915 SIP Phone - Quick Reference Guide

Note: For details on all the available features and options, refer to the *Mitel* 6915 SIP Phone User Guide.

User Interface (UI) overview

Home screen

The Home (default) screen is displayed when the phone is in the idle state. The Home screen displays the current line, status indicators, status messages, the date and time, and a list of configurable top and bottom softkeys.



Call screen

When on an active call, caller's avatar, name, number, and the call-duration timer are displayed. The context-sensitive softkeys are updated with applicable call-handling features.



Applications

Directory

The Directory application stores personal phone book and directory. The Mitel 6915 SIP phone supports a localized personal directory as well as enhanced functionality allowing for interoperability with LDAP (corporate) directories.



Making a call using the Directory

- 1. Press the A key to access the **Directory**.
- 2. Navigate to the respective contacts folder and scroll through the contacts by using the navigation keys



© Copyright 2024, Mitel Networks Corporation. All Rights Reserved.

58017009 REV00

The trademarks, service marks, logos and graphics (collectively "Trademarks") appearing on Mitel's Internet sites or in its publications are registered and unregistered trademarks of Mitel Networks Corporation (MNC) or its subsidiaries (collectively "Mitel") or others. Use of the Trademarks is prohibited without the express consent from Mitel. Please contact our legal department at legal@mitel.com for additional information. For a list of the worldwide Mitel Networks Corporation registered trademarks, please refer to the website: http://www.mitel.com/trademarks.

Mitel 6915 SIP Phone - Quick Reference Guide

or

Enter characters using the keypad and press the **Search** softkey to use the search feature

When the applicable contact is highlighted, press the Select button or the Dial softkey to place a call using the entry's default phone number or

To place a call to a different phone number defined for the entry (for example, a mobile number), press the right navigation key, highlight the phone number you want to call using the up or down navigation keys, and press the **Select** button or the **Dial** softkey.

Call History

The Call History application displays a list of your missed, outgoing and received calls. You can view, delete and dial out to call history entries as well as copy entries to your Contacts application.



Using the Call History application

- 1. Press the key to access the Call History application.
- 2. Scroll through the lists by using the navigation keys. To view additional details for an entry, press the **Right** navigation key when the entry is highlighted.
- 3. Press the **Select** button or **Dial** softkey to place a call to the respective entry

Press the **Copy** softkey to copy the entry to your Contacts application

Press the **Delete** softkey to delete the entry from your Call History.

Mitel® Powering connections

© Copyright 2024, Mitel Networks Corporation. All Rights Reserved.

Voicemail

When voicemail functionality is enabled, the MWI LED on the Mitel 6915 SIP phone flashes red and the (Voicemail) icon displays on the status bar indicating that voicemail messages are available.

You can access your voicemail service by pressing the Voicemail key.

Note: Voicemail functionality must be configured by your System Administrator.

58017009 REV00

The trademarks, service marks, logos and graphics (collectively "Trademarks") appearing on Mitel's Internet sites or in its publications are registered and unregistered trademarks of Mitel Networks Corporation (MNC) or its subsidiaries (collectively "Mitel") or others. Use of the Trademarks is prohibited without the express consent from Mitel. Please contact our legal department at legal@mitel.com for additional information. For a list of the worldwide Mitel Networks Corporation registered trademarks, please refer to the website: http://www.mitel.com/trademarks.